

LG QuantumFlux™ Pressurized UF Membrane

Technical Service Bulletin 607

UF System Troubleshooting

The UF system troubleshooting are covered in this TSB under two sections:

General Membrane Troubleshooting

Common UF System Troubleshooting Basics

If the operating problems are not addressed herein, contact LG Chem for support.

General UF Module Troubleshooting

The following are critical to maintain stable operation and produce high quality water over the long term:

- 1. Properly pre-treated feed water
 - 1) Pretreatment equipment should remain in proper working condition.
 - 2) Feedwater should be within the ranges provided in Table 1. The purpose of controlling these parameters is to minimize the risk of membrane damage and/or fouling. These ranges apply to all systems using LG Chem UF pressurized modules. Selection of operating parameters depends on the specific project.
- 2. Appropriate filtrate flux
- 3. Suitable filtration cycle time
- 4. Sufficient air scour flow rate
- 5. Targeted chemical cleaning regime

Feed water quality should be monitored closely. Changes in feed water quality may require adjustment of operational settings. Careful attention to how the membrane performance is affected by changing feed water quality is required to make necessary system adjustments.

Parameter	Allowed Range	Comments
рН	1 – 10 (NIPS) 1-14 (TIPS)	1—14 allowed during cleaning (TIPS)
Particle Size	≤0.5 mm, ≤0.12 mm for seawater feeds, no sharp particles allowed	To prevent mechanical damage
Oil	≤0.5 mg/L (NIPS) ≤2 mg/L (TIPS)	To prevent membrane fouling
Turbidity	<300 NTU	Contact the sales team if your operating parameters exceed the allowed



This is not an extensive list and does not constitute the only conditions for a valid warranty claim. Refer to your project specific warranty document for all conditions that apply to your warranty



LG QuantumFlux™ Pressurized UF Membrane

Technical Service Bulletin 607

UF System Troubleshooting

Common UF System Troubleshooting Basics

Symptom	Possible Causes	Solutions
High TMP	Fouling of the membrane	Undergo suitable cleaning; Adjust filtration flux; Adjust filtration cycle time; Verify automated cleanings are occurring correctly
Low air scouring flow rate	Blower fault	Check the blower
	Valve closed	Check the piping and valve
High feed water pressure	Control system failure	Check PID and flow meter
	Pressure meter fault	Calibrate the pressure meter
Low feed water	Feed pump failure	Check feed pump and piping
pressure	Valve failure	Check feed valve
Motor break down	No electricity	Check power supply
	VFD failure	Check the VFD unit
	Amperage Overload	Check the setting of overload for the motor. If the value is exceeded, contact the supplier.
IT failure	Membrane leakage	Check the transparent tube on the top of each module, locate the damaged module and repair it.
Valve failure	No open or close action	Check the compressed air. Check the solenoid valve.
	Switch fault	Check the switch and the 24V power supply.
High turbidity of product water	Air in the meter	Check the water pipe and eliminate the air.
	UF module integrity issue	Repair the damaged seal or fiber(s).

The information and data contained herein are deemed to be accurate and reliable and are offered in good faith, but without guarantee of performance. LG Chem assumes no liability for results obtained or damages incurred through the application of the information contained herein. Customer is responsible for determining whether the products

and information presented are appropriate for the customer's use and for ensuring that customer's workplace and disposal practices are incompliance with applicable laws and other governmental enactments. Specifications subject to change without notice. QuantumFlux is the Trademark of LG Chem. All rights reserved. © LG Chem, Ltd